

ADVANCED AEG

TAIWAN

(Head Quarter) No.999, Zhonghua Rd. Shengang Township,

Changhua County 50952, Taiwan (R.O.C.)

Taipei | Tel : +886-2-2692-2000 | Fax : +886-2-2692-4000 11F-3., No.27, Lane 169, Kangning St. Shijr City,

Taipei County 22180, Taiwan (R.O.C.)

Technology Dept. support@guay2.com

Sales Dept. | sales@guay2.com, b2b@guay2.com

PR Dept. pr@guay2.com

U.S.A.

Los Angeles | Tel : +1-626-581-0101 Fax: +1-626-581-1011









- All products employ a high precision 6.04mm barrel. Using 5.95mm BB pellets is highly recommended. Damage to the product due to faulty BB pellets voids the warranty. Use with caution.
- A The buyer and the user of this product shall adhere to all local laws regulating the usage and the ownership of airsoft guns.

You may be liable for damaging public, personal property, or for injuring a person or an animal. Always observe good manners and enjoy fun sport shooting.



Safety procedures:

- 1. Attach the safety cap to the muzzle.
- 2. Set the selector lever to the safety position
- 3. Remove the magazine.





- Read all instructions before using this product.
- Adult supervision required.
- Always wear safety goggles when using this product.
- Misuse or careless handling of this product may cause injury.
- May be hazardous up to 50 meters.



When you carry the air gun, attach the safety cap, set the selector lever to the safety position, and always put the air gun in a case or bag.



Select a safe place for operating the air gun and avoid places where people and cars are around.



Always attach the safety cap to the muzzle, remove the battery and store the air gun in a case or bag and at a place that is out of reach of children.

Orange tip disclaimer

- All G&G Airsoft guns come with a permanent fixed orange tip required by law, which will grant Airsoft legal usage in the United States.
- A If you alter, modify, abuse, or remove the orange tip, all warranty coverage will be void.



Looking into the muzzle is extremely dangerous, regardless of having BB's loaded or not. If you get hit in the eye by a BB pellet, worst case scenario, you may lose your eye sight

Never direct the muzzle

harm or damage to a third

There may be cases where some BB's remain in the gun after the magazine has been removed. After removal of the magazine, direct the muzzle towards a safe direction and pull the trigger to confirm that there are no BB's remaining in the gun, then attach the safety





please visit our website

www.guay2.com





Make sure to put the barrel and safety cap onto the muzzle except when shooting. to prevent any accidents, discharge of BB's, and also for dust protection purposes. Never pull the trigger while the barrel and safety cap are attached.



Activating the trigger carelessly is extremely dangerous. Never put your finger on the trigger unless the safety cap is removed and you are ready to shoot a target



Disassembling or modifying the gun may adversely affect the performance and make it dangerous. It would also void all warrantv.

























For more product information please visit our website







Magazine


































In order to simulate the bolt action of a real firearm, G&G is proud to present its new Pneumatic Blow Back system to its line of airsoft guns.

Conventional airsoft blow back utilizes tow hook springs that connect to the piston head and bolt plate to simulate bolt action, which often lead to excess wear and tear and poor reliability in the gear box. To alleviate the problem of conventional systems, G&G has independently developed the Pneumatic Blow Back system for a better solution on simulating bolt actions.

This new technology utilizes compressed air to move the bolt, which enables the action without adding extra stress to the gear box.

This class leading system represents a significant milestone in the airsoft industry.







TAIWAN

Patent No. M300797



US

Patent No. 11/488698



HONG KONG

Patent No. 06107627.0



.ΙΔΡΔΝ

Patent No. 實願2006-1459



EUROPEAN UNION

Patent No. 460191 814454



CHINA

Patent No. 200620122468,9



DENMARK

Patent No. BA2007 0069



II.K

Patent No. 614422.4







SELECTOR & SAFETY SETTING

G&GARMAMENT







A CAUTION

- Never operate the selector switch while pulling the trigger. Otherwise, malfunctions may occur.
- Pulling the trigger with the Selector being set at safe mode may damage the air gun.

SAFETY ON THE TRIGGER CANNOT BE PULLED



When the gun is in storage or not being fired, always set the selector to the Safe position and attach the protective cap on the muzzle.

FULL AUTO **AUTOMATIC FIRING**



The gun will fire continuously while the trigger remains pulled.

SEMI AUTO SINGLE SHOT



The gun will fire one shot each time when pulling the trigger.

SELES Manual

BATTERY SETTING 16



LED Indication

A CAUTION

Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

For GKM / GIMS / GK74 / GK74N



Push the button and pull forward to unlock the handquard battery.



Remove the handquard battery.

Power 1 Blue Light (ON)

[Error Status] Red Light (Flashing) / [Normal] Red Light (OFF) [Fully Charged] Green Light (ON) / [Normal] Green Light (OFF)

When the green light flashing more frequently shows the charging speed is faster. When the battery is nearly full, the green light will be on consistently.

A CAUTION

Make sure the longitudinal slits always present on pin connector. If the pin connector has been deformed, it may disable the firing function!







the two halves of the pin to

For RK103 EVO CRANE / RK104 EVO CRANE



- 1. Pull and hold the stock release lever mount.
- 2. Pull out the stock.



- 1. Turn and take off the battery cover.
- 2. Insert the battery into the stock.



- 1. Connect the battery plug into the connector until vou hear a 'click'.
- 2. Reinstall the stock.



SERVES Manual

For RK47 / RK103 / RK104 / RK103 EVO / RK104 EVO



Unscrew the fixing screws and remove the



Connect the battery until you hear a 'click'.



Insert the battery and reinstall the plate.


For RK Beta



Push the stock plate and remove.



Connect the battery plug with the connector until you hear a 'click'.



Reinstall the stock plate.

A CAUTION Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

For GK99



Unscrew the handquard cap.



Pull the handquard forward.



Remove the handquard and pull out the connector.

For GK99



Connect the battery plug with the connector until you hear a 'click', then insert the battery into the handguard.



Put the handguard back on.



Tighten up the handguard cap.





CAUTION Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

For GKS74U / GK74 Carbine / GKMS Carbine



Push the rear-end of spring guide to remove the top cover.



Insert battery and connect the connector until you heard the click sound.



Reinstall the top cover.

For GKMS / GKMS Carbine



Push the stock lock button to unlock.



Turn the folding stock to be locked.



Turn the stock bottom to be locked.

For GIMS



Push the stock lock button to unlock.



Turn the folding stock to be locked.

For GK74 / GKS74U



Push the stock lock button to unlock.



Turn the folding stock to be locked.

For GK99



Press and pull the stock to unlock.



Turn the folding stock to be locked.









CAUTION Confirm that the safety lever is set to the Safety position and do not place your finger on the trigger.

For All RK Series

A CAUTION

Always use the G&G BB pellet or diameter 5.94 ~ 5.96 mm BBs for this air gun. G&G shall not be held responsible for any damage or accidents arising from the use of pellets supplied by other manufacturers



Push the magazine catch to release the magazine.



Open the cover of magazine and load G&G 5.95mm BB pellets into the magazine.

For All RK Series



After the BB pellets have been loaded. close the cover and turn the gear on the bottom until the sound changes



Set the magazine upward.



Connect firmly till you hear a 'click'.

Front Sight Adiustment For All RK Series



Insert the front sight adjustment tool into the front sight block.



Turn for adjustment. Clockwise: Lower the front sight. Counterclockwise: Raise the front sight.

CAUTION Ensure not to lose the adjustment tool.

Rear Sight Adjustment For All RK Series (Apart from RK Beta / GK99)



Press the button and slide forward or backward for adjustment.

Rear Sight Adjustment

Front Sight Adjustment For GK99



Use the screwdriver to adjust the front sight windage.



Flip-Up night front sight.



Common shooting.



Precision shooting.

HOP-UP/ MOTOR GEAR ADJUSTMENT

G&GARMAMENT





CAUTION Do not to catch your fingers in the dummy bolt.


For All RK Series



Pull the handle in the direction shown to open the bolt.



Slide the hop-up adjustment piece forward or backward to adjust the Hop-up effect.





* NOTE | Adjust only when the gear noise becomes shrill.

For All RK Series



Unscrew the fixing screw on the bottom of the grip and remove the grip.



Adjust with hexagon key.

For GKS74U / GK74 Carbine / GKMS Carbine



- 1. Push the rear-end of spring guide.
- 2. Open the top cover.



Push the rear-end of the spring guide to remove the bolt set.



Use 2mm hexagon key to unscrew the barrel bracket set screws.

For GKM / GKMS / GIMS / GK74 / GK74N



Unscrew the screws of the Hop-up unit. The front kit can now be disassembled.



Push the button and pull forward to remove the handguard battery.



Unscrew the screw and the front kit can now be disassembled.





1. After Operation

Remove the magazine, direct the muzzle into a safe direction, then fire the qun in semi-auto mode for a few shots. Set the selector to the safe position.

Always disconnect the battery and attach the protective cap whenever you do not operate the air gun.

2. Cautions on Motor and Battery


Charge the battery if the firing cycle becomes slow.

Stop the usage of the air gun for 5 to 10 minutes after firing around 500 rounds in order to ensure the long life of the motor and battery.

3. Cloqued Pellets

If pellets are cloqued, remove and apply a few drops of G&G's silicone oil into the chamber from the magazine entrance. Apply the silicone for 0.4 to 1 sec to obtain smooth continuous firing.

WHEN PELLET SPEED BECOMES LOW



- 1. Place a few drops of silicone oil or teflon oil into the pellet entrance. After inserting BB pellets into the magazine, fire the gun around 200-300 rounds.
- 2. To complete the cleaning, use the cleaning rod (with cotton) to remove excess oil.

Make sure no dirt gets into the chamber to avoid clogging of pellets. CAUTION The hopping up operation may be unstable for the first 200 to 300 rounds after using silicone oil, this is the normal operation fo the qun.



REMOVING CLOGGED PELLETS



- 1. Return the hop-up dial to the Normal position and insert the cleaning rod from the lead edge of the barrel.
- 2. To remove clogged BB's, carefully insert the cleaning rod inside with the flat tip facing down as shown below.

III Disclaimer

- Accessories pictured are not always included with product.
- Adult supervision required for users under 18 years of age.
- The purchaser and user should conform to all laws governing the ownership of airsoft guns.
- All products in this manual are imitation firearms and are not intended nor represented to be comparable in design, appearance, or function to any actural firearm offered by other manufacturers.
- Product names are trademarks of G&G, which has no affiliation to, and is not associated, or sponsored by any manufacturer of actual or imitation firearms. Products may vary form those pictured.

III Troubleshooting

SYMPTOM	POTENTIAL	CORRECTIVE	
	Selector lever is set to safety.	Set the selector lever to Semi or Full Auto.	
	Battery is not charged.	Charge the battery.	
No operation at all	Battery connector is disconnected.	Connect the connector.	
No operation at all	The ⊕and ⊕of battery connector is reversed.	Switch the batteries to the correct position.	
	Expired motor life (50,000 to 60,000 rounds) or poor electrical connection.	Replace the dead motor (can be purchased from local dealer or directly from G&G). Check and repair the contacts.	
Although motor is revolving, no	Pellets are clogged inside the magazine.	Insert the charging rod into the magazine and move up and down a few times to remove clogged pellets.	
pellet can be fired	Pellets are clogged in the chamber.	Remove clogged pellets using the cleaning rod.	
•	Faulty gear.	Purchase the replacement gear from your dealer or G&G and repair.	
1	Insufficient battery power.	Charge the battery.	
Impossible full-auto	Faulty pellet feed of magazine.	Repair clogging of the magazine.	
operation(automatic firing)	Poor electrical connection.	Consult your dealer or G&G for overhaul maintenance or repair.	
	Damaged or worn chamber set.		
	Damaged or worn piston set (O-ring,piston spring)	Replace the replacement parts (purchase from your dealer or G&G)	
Shooting distance becomes shorter	Something is jammed in the inner barrel	Use the cleaning rod and clean the inner barrel.	
	Faulty BB pellets (too small or heavy)	Use the genuine G&G Pellets.	
	Shortage of silicone oil	Place a few drops of silicone oil onto the upper chamber.	
	Gear problem caused by too many blank firing		
Loud apprating poins	Worn or damaged gear	0	
Loud operating noise	Gear problem caused by too many blank firing	Consult your dealer or G&G for overhaul maintenance, part replacement (gear,etc.) or repair.	
Pellets being fallen out from barrel end	Damaged or worn chamber set.	(goal, sto.) of repair.	
	No hop setting.	Turn the hop adjustment lever toward Hop.	
	Faulty BB Pellets (too small or heavy)	Use the G&G Pellets.	
If gun gets wet	Stop operation immediately, disconnect the battery, wipe off water from inside the main body and the battery. After the gun is completely dry, carry out trial firing. If the unit is not operational, please contact your local dealer for repair.		



CAUTION Do not jam the cleaning rod into the barrel by force. Should the BB's remain inside the barrel after following the instruction above, point the gun to a safe direction and discharge any loosened BB's in semi-automatic mode.

for RK47

You may buy all groups' parts

Email: support@guay2.com

from G&G Support Dept.

G&G WWW.Guay2.com ARMAMENT





PARTS LIST

for RK47

Receiver Cover Set Rear Sight Set

Bolt Set RK47-003

RK47-004 Gas Block Set

Rail Mount Set RK47-005

RK47-006 Receiver Set

Barrel Base Set RK47-007

Gas Cylinder Set RK47-008

Outer Barrel Set RK47-009

Front Sight Set RK47-010

Butt Stock Set RK47-011

Selector Lever Set RK47-012

RK47-013 Gear Box Set

RK47-014 Hop Up Set

Inner Barrel RK47-015

Clean Rod RK47-016

Grip Set RK47-017

Motor Base Set RK47-018


RK47-019 Motor Set

Handguard Set RK47-020

Trigger Guard Set RK47-021

Magazine

















Rear Sight Set **Bolt Set** Receiver Set Barrel Base Set Gas Cylinder Set Butt Stock Set RK103-012 Selector Lever Set Gear Box Set Hop Up Set RK103-017 Grip Set Motor Base Set RK103-018 Motor Set RK103-019 RK103-020 Handquard Set **Trigger Guard Set** RK103-021 RK103-022 Magazine


for RK103

RK103-004 Gas Block Set RK103-005 Flash Suppressor Set RK103-009 Outer Barrel Set RK103-010 Front Sight Set RK103-015 Inner Barrel RK103-016 Clean Rod

for RK104


RK104-005 Flash Suppressor Set RK104-009 Outer Barrel Set RK104-010 Front Sight Set RK104-015 Inner Barrel RK104-016 Clean Rod


















for RK103 EVO / RK104 EVO RK103E-001 Receiver Cover Set


RK103E-001	Receiver Cover Se
RK103E-002	Rear Sight Set
RK103E-003	Bolt Set
RK103E-006	Receiver Set
RK103E-007	Barrel Base Set
RK103E-008	Gas Cylinder Set
RK103E-011	Butt Stock Set
RK103E-012	Selector Lever Set
RK103E-013	Gear Box Set
RK103E-014	Hop Up Set
RK103E-017	Grip Set
RK103E-018	Motor Base Set
RK103E-019	Motor Set
RK103E-020	Handguard Set
RK103E-021	Trigger Guard Set
RK103E-022	Magazine

for RK103 EVO

RK103E-004	Gas Block Set
RK103E-005	Flash Suppressor S
RK103E-009	Outer Barrel Set
RK103E-010	Front Sight Set
RK103E-015	Inner Barrel
PK103F-016	Cloan Pod

for RK104 EVO

RK104E-0	05	Flash Suppressor So
RK104E-0	09	Outer Barrel Set
RK104E-0	10	Front Sight Set
RK104E-0	15	Inner Barrel
RK104E-0	16	Clean Rod







PARTS LIST for RK103 EVO CRANE / RK104 FVO CRANE

RK103EC-01 Receiver Cover Set Rear Sight Set Bolt Set Receiver Set Barrel Base Set Gas Cylinder Set **Butt Stock Set**

Selector Lever Set Gear Box Set

Hop Up Set RK103EC-14

Grip Set

Motor Base Set

Motor Set

Handquard Set

Trigger Guard Set

Magazine

RK103EC-23 Cord Set

for RK103 EVO CRANE

RK103EC-04 Gas Block Set RK103EC-05 Flash Suppressor Set

RK103EC-09 Outer Barrel Set

RK103EC-10 Front Sight Set

RK103EC-15 Inner Barrel

RK103EC-16 Clean Rod


for RK104 EVO CRANE


RK104EC-05 Flash Suppressor Set

Outer Barrel Set

RK104EC-10 Front Sight Set

RK104EC-15 Inner Barrel RK104EC-16 Clean Rod









for RK BETA

Receiver Cover Set **Bolt Set** RKBETA-002

Flash Suppressor RKBETA-003

Magazine RKBETA-004

Receiver Set RKBETA-005

RKBETA-006 Barrel Base Set

Gas Cylinder Set RKBETA-007

Front Sight Set RKBETA-008

Butt Stock Set RKBETA-009

Selector Lever Set RKBETA-010

RKBETA-011 Gear Box Set

RKBETA-012 Hop Up Set

Outer Barrel RKBETA-013

Inner Barrel RKBETA-014


Grip Set RKBETA-015


Motor Base Set RKBETA-016

Motor Set RKBETA-017

Rail Handgurad Set RKBETA-018

Trigger Guard Set RKBETA-019






G&G WWW.Guay2.com ARMAMENT






PARTS LIST

for GK99 BlowBack Ver.





for GK99 BlowBack Ver.

GK99BB-001 Receiver Cover Set

GK99BB-002 Bolt Lever Set

GK99BB-003 Bolt Guide Set

GK99BB-004 Gas Tube

GK99BB-005 Receiver Set

GK99BB-006 Handguard Set

GK99BB-007 Gas Block Set

GK99BB-008 Front Sight Set

GK99BB-009 Flash Suppressor

GK99BB-010 Folding Stock Set

GK99BB-011 Grip

GK99BB-012 Selector Lever Set

GK99BB-013 Gear Box Set

GK99BB-014 Hop Up Set

GK99BB-015 Outer Barrel Set


GK99BB-016 Inner Barrel

GK99BB-017 Motor Base Set


GK99BB-018 Motor Set

GK99BB-019 Trigger Guard Set

GK99BB-020 Magazine







PARTS LIST \40

for GK47	/ GK74N	/ GKS74U
----------	---------	----------

GK74 - 012 Selector Lever Set

GK74 - 014 Hop Up Set GK74 - 017 Grip Set

Motor Base Set Motor Set

GK74 - 019 GK74 - 021 Trigger Guard Set

GK74 - 022 Magazine

for GK47 / GK74N

GK74 - 001 Receiver Cover Set Rear Sight Set

GK74 - 003 Bolt Set

Gas Block Set

Flash Suppressor Set

Barrel Base Set Gas Cylinder Set

Outer Barrel Set

Front Sight Set GK74 - 013 Gear Box Set

GK74 - 015 Inner Barrel

GK74 - 016 Clean Rod

Handguard Battery Set

GK74 - 023 Cord Set

GK74 - 024 Battery Charger Set

for GK74 / GKS74U

GK74 - 006 Receiver Set <u>G</u>K74 - 011 Folding Stock Set

for GKS74U

Receiver Cover Set

Bolt Set GKS74U-003

Flash Suppressor Set GKS74U-005

Gas Cylinder Set GKS74U-008 GKS74U-009 Outer Barrel Set

GKS74U-010

Front Sight Set


Inner Barrel GKS74U-015

GKS74U-020 Handquard Set


for GK74N

Receiver Set

GK74N-006 GK74N-011 Butt Stock Set







PARTS LIST YE

for GIMS / GKM

SIMS - 001	Receiver Cover Set
GIMS - 002	Rear Sight Set
GIMS - 003	Bolt Set
GIMS - 004	Gas Block Set
GIMS - 005	Flash Suppressor Set
GIMS - 007	Barrel Base Set
3IMS - 008	Gas Cylinder Set
GIMS - 009	Outer Barrel Set
GIMS - 010	Front Sight Set
3IMS - 012	Selector Lever Set
3IMS - 013	Gear Box Set
GIMS - 014	Hop Up Set
3IMS - 015	Inner Barrel
3IMS - 016	Clean Rod
GIMS - 017	Grip Set
3IMS - 018	Motor Base Set
3IMS - 019	Motor Set
3IMS - 021	Trigger Guard Set
GIMS - 022	Magazine
3IMS - 023	Cord Set

for GIMS

GIMS - 006	Receiver Set
GIMS - 011	Folding Stock Set
GIMS - 020	Handguard Battery Set

GIMS - 024 Battery Charger

for GKM


GKM - 006	Receiver Set
GKM - 011	Butt Stock Set
GKM - 020	Handguard Battery Set




ADVANCED SERVES MANUAL

PARTS LIST 744

for GKMS





for GKMS


GKMS - 001	Receiver Cover Set
GKMS - 002	Rear Sight Set
GKMS - 003	Bolt Set
GKMS - 004	Gas Block Set
GKMS - 005	Flash Suppressor Se
GKMS - 006	Receiver Set
GKMS - 007	Barrel Base Set
GKMS - 008	Gas Cylinder Set
GKMS - 009	Outer Barrel Set
GKMS - 010	Front Sight Set
GKMS - 011	Folding Stock Set
GKMS - 012	Selector Lever Set
GKMS - 013	Gear Box Set
GKMS - 014	Hop Up Set
GKMS - 015	Inner Barrel
GKMS - 016	Clean Rod
GKMS - 017	Grip Set
GKMS - 018	Motor Base Set
GKMS - 019	Motor Set
GKMS - 020	Handguard Battery S
GKMS - 021	Trigger Guard Set
GKMS - 022	Magazine
GKMS - 023	Cord Set
GKMS - 024	Battery Charger




STATES Manual

PARTS LIST 45

for GKMS Carbine / GK74 Carbine





for GKMS Carbine / GK74 Carbine

GKMS C - 03	Bolt Set
GKMS C - 05	Flash Suppressor Set
GKMS C - 08	Gas Cylinder Set
GKMS C - 09	Outer Barrel Set
GKMS C - 10	Front Sight Set
GKMS C - 12	Selector Lever Set
GKMS C - 13	Gear Box Set
GKMS C - 14	Hop Up Set
GKMS C - 15	Inner Barrel
GKMS C - 17	Grip Set
GKMS C - 18	Motor Base Set
GKMS C - 19	Motor Set
GKMS C - 20	Handguard Set
GKMS C - 21	Trigger Guard Set

GKMS C - 01 Receiver Cover Set

for GKMS Carbine

GKMS C - 06	Receiver Set
GKMS C - 11	Folding Stock
GKMS C - 22	Magazine

for GK74 Carbine

GK74 C - 06	Receiver Set
GK74 C - 11	Folding Stock Set
GK74 C - 22	Magazine